

09111 Belt Spray

Belt Spray prevents the fan belt and cooler belt from slipping and making irritating noise. It also protects rubber and prevents it from deteriorating. The long nozzle is included.

Directions

*Be sure that the engine is stopped.

1. Shake the can well and insert the included long nozzle into the can.

*Do not turn the nozzle toward the face.

2. Spray to the inner side of the belt and the slit of the pulley for 4-5 seconds. Turn on the engine to move the belt, making the inner side of the belt get wet evenly. Repeat the same process a few times.

Spec info.

40ml

Case dimension

W 520 H 240 D 210 mm

Case weight

4.0 kg

Case unit

50

Control No.

B-111

JAN code

4 975759 091110

09112 Radiator Stop Leak

By simply pouring it into the radiator, Radiator Stop Leak covers over the hole or crack and stops a leak. If you pour it in advance, it prevents the radiator from those troubles.

Directions

*Be sure that the engine is stopped.

1. Shake the bottle well, take off the radiator cap and pour the liquid into the radiator. Afterward fill the coolant to the right level.

2. Tighten the radiator cap and turn on the engine to let the coolant circulate inside. The leak stops as soon as that.

3. When you use it to old radiator, remove rust or dirt in advance.

Spec info.

125ml

Case dimension

W 500 H 300 D 210 mm

Case weight

7.0 kg

Case unit

50

Control No.

B-112

JAN code

4 975759 091127