

11101 Injection & Carb Cleaner

It removes dirt such as carbon or sludge accumulating on the inside of the injector or combustion chamber, and restores the engine power.

Directions

1. Leave the car idling for approximately 5-6 minutes to warm the engine.
2. Stop the engine and loosen the rubber hose a bit to make enough space to insert the tube to let you spray toward the throttle chamber.
3. Turn on the engine and use a whole bottle while keeping idling at about 2000 times engine rotation.
4. Meanwhile leave it for approximately 5-6 minutes after the engine stops, and reset the rubber hose. Afterward turn on the engine and snap until white smoke is not produced.

*Be sure not to spray over the Air flow meter.

Spec info.

300ml

Case dimension

W 264 H 217 D 330 mm

Case weight

7.6 kg

Case unit

20

Control No.

-

JAN code

4 975759 111016

11102 Engine Conditioner

By Just spraying through the air inlet, without disassembling the engine, it removes dirt caused by varnish or carbon from the combustion chamber or the carburetor, and restores its power while normally adjusting the engine.

Directions

1. Leave the car idling for 5-6 minutes to warm the engine.
2. Stop the engine and loosen rubber hoses a bit to make enough space to insert the tube allowing you to spray toward the throttle chamber.
3. Turn on the engine and use a whole bottle while keeping the engine idling at about 2000 times engine rotation.
4. Meanwhile leave it for 5-6 minutes after the engine stops, and reset the rubber hose. Afterwards turn on the engine and snap until white smoke is not produced.
5. Perform this process as needed.

Spec info.

300ml

Case dimension

W 264 H 199 D 330 mm

Case weight

7.1 kg

Case unit

20

Control No.

-

JAN code

4 975759 111023

00492 Engine Room Wipe

These newly developed sheets are hard to get stuck and be shaped into a ball, which allows for more efficient absorption of unwanted residue, oily dirt and prevents them from re-appearing. It can also maintain a clean engine room for a long period of time because it displays both effects of protection and a glossy finish.

Directions

1. Be sure that the engine stops and the engine room is cooled down.
2. Take out a sheet from the package and wipe with it.
3. If the sheet gets dirty, refold it and continue to use a cleaner side as needed.

Spec info.

10 sheets

Case dimension

W 383 H 207 D 408 mm

Case weight

kg

Case unit

60

Control No.

W-134

JAN code

4 975759 004929

03113 Teflon Chain Lube

The oil chain can correspond to every kind of chain. Blended Teflon which has rub resistance and durability reduces friction and irritating noises, and maintains its smoothness.

Directions

*Be sure that the engine stops.

*Shake the can well.

1. Remove dirt from the chain in advance.
2. Spray it little by little with a spot shape while twirling the chain using your hands slowly.
3. Rotate the chain to let the oil go throughout.
4. Let sit for approximately 10 minutes before driving in order to prevent the oil from being splattered.

Spec info.

420ml

Case dimension

W 288 H 213 D 360 mm

Case weight

9.0 kg

Case unit

20

Control No.

E-37

JAN code

4 975759 031130

03018 Oil Spray

Oil Spray maintains the metallic parts well-oiled, and protects from rust. It keeps the electrical system in a dry condition, and prevents faulty junction. It also permeates faster, speeding up the desired effects. The free-action nozzle allows you to spray it at various angles and you can toggle the patterns of the jet nozzle as well.

Directions

1. Shake the can well and spray it over the desired area evenly.
2. When you spray it on a narrow or rear area, turn up the nozzle and then spray.

Spec info.

220ml

Case dimension

W 274 H 195 D 327 mm

Case weight

7.5 kg

Case unit

30

Control No.

E-11

JAN code**03022 Grease Spray**

This grease which resists heat and pressure displays its efficient lubricating and rust free effects lasting for longer periods of time with high viscosity. The free-action nozzle allows you to spray it at various angles and you can toggle the patterns of the jet nozzle as well.

Directions

1. Shake the can well and spray it over the desired area evenly.
2. When you spray it on a narrow or rear area, turn up the nozzle and then spray.

Spec info.

220ml

Case dimension

W 274 H 195 D 327 mm

Case weight

7.5 kg

Case unit

30

Control No.

E-12

JAN code**03121 Paste Grease**

<Super resistant against heat and pressure grease>

Compared to the spray type, this paste type grease will provide sufficient durability and resistance against heat and pressure.

Directions

1. Remove old grease or dirt from the desired area in advance.
2. Prepare a moderate amount of the grease and apply it to desired area.

Spec info.

280ml

Case dimension

W 360 H 167 D 453 mm

Case weight

13.5kg

Case unit

40

Control No.

E-26

JAN code